



The DTC can only support 4 ICRs.
Does not support multi-drop.



NOTE:
Gasboy DPC can be
multi-dropped up to
16 fueling points.

OPW
A DOVER COMPANY

Gasboy DTC
DTC Wiring Diagram
M1018-GASBOY, REV. 0



Terminal Comm Wires
RS-485 Twisted Pair

OPW Petro-Net
Cable Part # 12-1029
(twisted pair RS-485)

Gasboy Pump Control Wires
RS-485 Twisted Pair
(POLARITY IS IMPORTANT!)

Line, Neutral, Ground - must use a minimum of 14 AWG
copper wire inside 1/2" or 3/4" rigid steel conduit.

It is acceptable for DPC and DTC to share the same breaker.

NOTE: All Grounding Connections must
connect to Service Panel Ground Lugs



GASBOY DISPENSER