


SiteSentinel™ 2 and 3



SiteSentinel 2 and 3 Parts

1. Model 2 Buzzer	06-2005
2. Model 2 Keyboard	09-4011
3. Model 2 Graphics Display	20-4147
4. Model 2 Light/Alarm Switch Assembly.....	20-5028
5. Corcom Filter.....	02-4001
6. PV235 Internal Modem Board Assembly	20-0288-1
7. 110V Controller Transformer	20-5026
8. 230V Controller Transformer	20-5026-230
9. Model 2 Paper Spindle.....	50-3048
10. Model 2 Report Printer Paper.....	54-1102
11. Model 2 Printer Ribbon.....	75-1007
12. PV235 Controller Board	R20-0226
13. PV250 Comm Terminal Board	R20-0227
14. Corcom Filter.....	02-4001
15. Interface Module	20-4323
16. 110V Transformer.....	20-5027
17. 230V Transformer	20-5027-230
18. Circuit Breaker	48-0004
19. PV256 Smart Module Controller Board	R20-0256-1
20. Report Printer Assembly	R20-4300
21. Paper Tear Bar.....	50-3049
22. Smart Module Software.....	S05701
23. SiteSentinel 2 Controller Software.....	S05601
24. PV271 System2 FSC Board.....	R20-0271
25. PV271 Battery.....	48-0204
26. 120/18VAC External Transformer Assembly.....	07-0041
27. 240/18VAC External Transformer Assembly.....	07-0042
28. PC/CRT Cable.....	20-1478
29. PetroNet Cable.....	20-1443
30. Printer Cable.....	20-1444