




# OPW Installation and Maintenance Instructions

## OPW 62M Monitoring Probe Caps



### Product Identification:

Manufacture: "OPW"

Model: "62M"

Date Manufactured (Located on underside of cap): "MFG MMY"; MM = Month, YY = Year

**IMPORTANT:** Please read these warnings and use the assembly instructions completely and carefully before starting. Failure to do so may cause product failure, or result in environmental contamination due to liquid leakage into the soil, creating hazardous spill conditions.

**IMPORTANT:** Check to make sure the unit is intact and undamaged and all parts have been supplied. Never substitute parts for those supplied. Doing so may cause product failure.

**WARNING-DANGER:** Using electrically operated equipment near gasoline or gasoline vapors may result in a fire or explosion, causing personal injury and property damage. Be sure that the working area is free from such hazards, and always use proper precautions.

**NOTE:** At all times when product is in the storage tank keep the riser pipe capped, so the vapors cannot escape into the environment.

**NOTICE:** OPW products must be used in compliance with applicable federal, state, and local laws and regulations. Product selection should be based on physical specifications and limitations and compatibility with the environment and material to be handled. All illustrations and specifications in this literature are based on the latest production information available at the time of publication. Prices, materials, and specification are subject to change at any time, and models may be discontinued

at any time, in either case, without notice or obligation.

### **Standard Product Warranty**

*OPW warrants that products sold by it are free from defects in materials and workmanship for a period of one year from the date of manufacture by OPW (ECO products two years from date of manufacture.) Proof of purchase may be required. As the exclusive remedy under this limited warranty, OPW will, at its sole discretion, repair, replace, or issue credit for future orders for any product that may prove defective within the one-year date of manufacture period (repairs, replacements, or credits may be subject to prorated warranty for remainder of the original warranty period, complete proper warranty claim documentation required.) This warranty shall not apply to any product that has been altered in any way, which has been repaired by any party other than a service representative authorized by OPW, or when failure is due to misuse, or improper installation or maintenance. OPW shall have no liability whatsoever for special, incidental or consequential damages to any party, and shall have no liability for the cost of labor, freight, excavation, cleanup, downtime, removal, reinstallation, loss of profit, or any other cost or charges.*

*For any product certified to California 2001 standards, OPW warrants that products sold by it are free from defects in material and workmanship for a period of one year from date of manufacture or one*

*year from date of registration of installation not to exceed 15 months from date of manufacture by OPW.*

**THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, AND SPECIFICALLY THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THERE ARE NO WARRANTIES, WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF.**

**Installation and Maintenance:**

1. Install the 62M Monitoring Cap onto a FSA-400(-S) Face Seal Adapter. (Optional) Apply pipe dope to nipple.
2. Tighten Monitoring Cap onto the FSA-400(-S) adapter with a strap wrench. Torque to be 90 ft-lbs to 110 ft-lbs.
3. Remove plug and install wire grommet if needed. Apply gasoline resistant pipe dope to threads. (Torque values: 3/8 NPT thread; 20 in-lbs to 40 in-lbs. 1/2 NPT thread; 30 in-lbs to 50 in-lbs).

Annually inspect O-ring and Gasket seal for nicks, tears or deformations. If required replace with OPW Part numbers: O-ring: H13806M, Gasket: H09039M.



P.O. Box 405003 \* Cincinnati, Ohio 45240-5003  
1-800-422-2525 Domestically  
513-870-3315 Internationally  
[www.opw-fc.com](http://www.opw-fc.com)

Copyright, 2006 – 2006 OPW Fueling Components Inc., Cincinnati, OH

Printed in U.S.A. p/n 200654 Rev. A – 9/06