


Pipe Cutters & Jacket Strippers

The FlexWorks pipe cutter is designed to produce a clean and even pipe cut, which is necessary for proper coupling attachment. The FlexWorks Jacket Stripper is a tool used to remove a section of the secondary outer jacket of the FlexWorks Double-Wall piping. This is required for installation of swivel pipe couplings.

NOTE: When using double wall pipe couplings, do not trim piping secondary.



Pipe Cutter
(PCT-1000)

Jacket Strippers
(JCT-0075, 0100, 0150, 0200, 0300)

Ordering Specifications - Pipe Cutter and Jacket Stripper

Model #	Application
SPC-400	4" Access Pipe Cutter
PCT-1000	Pipe Cutter
PCB-2000	Pipe Cutter Blade for PCT-1000
JCT-0075	3/4" Jacket Cutter
JCT-0100	1" Jacket Cutter
JCT-0150	1.5" Jacket Cutter
JCT-0200	2" Jacket Cutter
JCT-0300	3" Jacket Cutter
JCB-1000	Jacket Cutter Blades for JCT-0075, JCT-0100, JCT-0150, JCT-0200 and JCT-0300

Fishing Bullnose

An attachment for the end of a flexible pipe section, used to aid in fishing the flexible pipe section through the access pipe. There are a variety of bullnoses available to connect to swivel couplings.

NOTE: 3/4" and 1" fishing bullnose are female threaded to accommodate 3/4" or 1" couplings.



Ordering Specifications - Fishing Bull Nose

Model #	Application	Model #	Application
FBN-2075	3/4" Fishing Bull Nose	FBN-2200	2" Fishing Bull Nose
FBN-2100	1" Fishing Bull Nose	FBN-3200	2" Bull Nose Plug
FBN-2150	1.5" Fishing Bull Nose		

Urethane Sealant

An all-purpose sealant. Can be used as an entry fitting sealant as well as to bond dispenser tops.

Ordering Specifications - Urethane Sealant

Model #	Application
SL-1100	Urethane Sealant (10.3 oz. Cartridge)