

PA800 Series Parking Adaptor

PA800 Series Parking Adaptors for API couplers ensure bottom loading arms are correctly stowed and secured. Some can also be used to collect drips and pipe them away to a drain system.

The bottom loading coupler is coupled and an integral proximity sensor (supplied separately) is actuated to enable system interlocks. All adaptors have stops to ensure coupler can not be opened whilst parked.

Key Features

- All adaptors have stops to ensure coupler can not be opened whilst parked.
- Some parking adaptors can be used to collect drips and pipe them away to a drain system.
- Parking adaptors can be supplied with a promixity swtich to enable system interlocks.

Ordering Information

PA801	API Parking Adaptor
PA811	API Parking Adaptor with Proximity Sensor Holder
PAS801	API Parking Adaptor c/w Stand, Straight
PAS811	API Parking Adaptor c/w Stand, Straight, with Proximity Sensor Holder
PAA801	API Parking Adaptor c/w Stand, Angled
PAA811	Api Parking Adaptor c/w Stand, Angled , with Proximity Sensor Holder


Specifications

Dismantle	Remove back plate and the nylon setscrew if dismantling to access proximity sensor is necessary.
Adjustment or Service	Periodically grease sliding proximity switch (where supplied) by using grease nipple visible from face of nosecone.
Materials of Construction	Nosecone - Aluminium Spring - Stainless steel Slider - Acetal Stand - Painted steel
Mounting	PA801 & PA811 bolt onto bracket supplied by customer PA80x & PA81x are free standing (bolt to concrete or skid floor)
Weight	PA801 - 0.9kg
Associated Equipment	API700 Series Dry-Break Coupler API800 Seires Dry-Break Coupler 5544 Proximity Switch Sensor


Page 1



www.liquip.comM:\Product-Info\PAxxx\8-Sales\PA800 Series Datasheet.pdfIssue: A07/09/15



Page 2



Page 3