


FSC3000™ Fuel Site Controller




FSC3000™
Fuel Site Controller

FSC3000™ Fuel Site Controller Parts

1. FSC3000 Internal Modem.....	75-2037
2. FSC3000 Main Board.....	20-0380
3. FSC3000 SIMM Module.....	20-0381-03*
4. Cable FSC3000 Printer.....	20-1517-05
5. Ethernet Cable RJ45 to RJ45.....	20-1613
6. Network Modem Cable.....	20-1517-01
7. PC/CRT Cable.....	20-1520-01
8. Journal Printer with Cable.....	20-7073
9. Network Modem.....	20-7078
10. FSC to Tank Gauge Cable Kit (not shown) (consists of 20-1613, 20-1614 and 20-1615).....	20-4267
11. FSC3K Artware Config. Software (not shown).....	S030300
12. FSC3000 Installation Manual (not shown).....	M030000.01

* Requires configuration


System2 Fuel Site Controller



System2 FSC Parts

1. PV271 System2 FSC Board.....	R20-0271
2. PV271 Battery.....	48-0204
3. Printer.....	20-7050
4. Printer Cable.....	20-1444
5. 1200/2400 Baud External Dial-In Modem.....	20-7052
6. Network Dial-Out Modem.....	20-8049
7. Modem Power Pack.....	07-0046
8. Modem Cable.....	20-1456
9. PC/CRT Cable.....	20-1478
10. PetroNet Cable.....	20-1443
11. 120/18VAC External Transformer Assembly.....	07-0041
12. 240/18VAC External Transformer Assembly.....	07-0042

K800™ Hybrid FIT



K800 Pedestal

K800 Hybrid FIT Parts

1. PV247 Fuel Island Terminal Board.....	R20-0222
2. 115V Heater Assembly.....	20-4138
3. 230V Heater Assembly.....	20-4138-230
4. PV240 Pump Relay Board.....	R20-0218
5. PV247 to PV240 Cable.....	20-1442
6. Heater Relay.....	06-0015
7. Fuel Island Terminal Power Switch.....	09-0007
8. Corcom Filter.....	02-4001
9. 110V Fuel Island Terminal Transformer Assembly.....	20-5023
10. 230V Fuel Island Terminal Transformer Assembly.....	20-5023-230
11. PV241 K800 Display Assembly.....	20-0219
12. Fuel Island Terminal Main Cable.....	20-1441
13. Keypad Assembly.....	20-4136
14. ChipKey® Reader Assembly.....	20-4117
15. K800 Pedestal.....	20-4137
16. Magnetic Cardreader for K800 Hybrid.....	75-3012